

Meander pantograph

Paper pantograph

Repeat width 12.00 in | Row height 5.00 in | Row spacing 5.00 in

Printed length 60.0 in on 7 sheets

Free pantograph from pantomaker.com

Stitch it on any quilt, including quilts you sell

How to put it together

1. Print every page at 100% ("Actual size", no "Fit to page"). The square below must measure 1 inch.
2. Lay the sheets in page order. Each sheet repeats the last 1/2 inch of the one before it:
slide it over the previous sheet until the drawing lines up, then tape the seam.
3. The arrow marks where the stitching line starts. Short ticks along both edges mark each repeat.
4. Dashed lines are the rows above and below, to help you line up the next pass.















